


TEST SETUP FOR BLADDER TANK/ HIGH-EXPANSION FOAM SYSTEM



- NOTES:
- 1.) MULTIPLE FOAM PROPORTIONERS CAN BE TESTED SIMULTANEOUSLY
 - 2.) LOCATE PLANIT SAFE[™] INLET CONNECTIONS AS CLOSE AS POSSIBLE TO FOAM CONCENTRATE ISOLATION VALVE
 - 3.) REFER TO GENERAL NOTES SHEET FOR ADDITIONAL INFORMATION

FOAM CONCENTRATE

WATER

SOLUTION